

UNIVERSAL REMOTE INSTRUCTIONS



**NOT FOR USE WITH ANY GARAGE DOOR OPENER MANUFACTURED PRIOR TO 1993.
SAFETY BEAMS (PHOTOCELLS) MUST BE IN PLACE AND OPERATIONAL.**

Below are the brands and specifications that this remote is compatible with and the available methods that can be used to program them. Review Chart A for compatibility and method, then proceed to STEP 1.

Chart A

AVAILABLE PROGRAM METHOD		QUICK START METHOD	LEARN METHOD
Brand Name	Garage Door Opener or Gate Receiver Specification Notes	Pre-set Button Number on Remote	Number of Button Presses
Genie®	315/390 MHz, Intellicode® I, 1995-current	1	1
Overhead Door®	315/390 MHz, CodeDodger® I, 1995-current	1	1
Chamberlain® LiftMaster® Craftsman®	Purple Learn Button, Security +®, 2006-2014, 315 MHz	2	2
	Orange/Red Learn Button, Security +®, 1996-2005, 390 MHz	3	3
	Yellow Learn Button, Security +2.0®, 2011-current, 390 MHz	4	4
	Green Learn Button, Billion Code®, 1993-1995, 390 MHz		5
Genie®	315/390 MHz, Intellicode® II, 2010-2011		6
Overhead Door®	315/390 MHz, CodeDodger® II, 2010-2011		6
Sommer®	310 MHz, Rolling Code		7
Linear®	318 MHz, Mega Code®		8
Wayne Dalton®	372.5 MHz, Rolling Code, 1999-current		9
Ryobi®	372.5 MHz, Rolling Code		10
Guardian®	303 MHz, Fixed Learn Code		11
Xtreme® brand	303 MHz, Fixed Learn Code		11
Marantec®	315 MHz, Fixed Learn Code		12

Cloning

- TEACH & PAIR -
Must have existing operational remote.

Genie® and Intellicode® are registered trademarks of The Genie Company. All other listed names and trademarks are the property of their respective owners.

NOTE: During programming, the garage door opener will operate. Ensure that the garage door opening is clear of personnel or any obstructions.